

14 Channels Mode			5 Channels Mode		
Channel	DMX Value	Function	Channel	DMX Value	Function
CH1	000-255	Dimmer	CH1	000-255	Dimmer
CH2	000-255	Red	CH2	000-255	Red
CH3	000-255	Green	CH3	000-255	Green
CH4	000-255	Blue	CH4	000-255	Blue
CH5	000-255	Strobe	CH5	000-255	Strobe
CH6	000-255	Program 1			
CH7	000-255	Program 2			
CH8	000-255	Program 3			
CH9	000-255	Program Size (Small to Big)			
CH10	000-255	Program Speed			
CH11	000-255	Program background Red			
CH12	000-255	Program background Blue			
CH13	000-255	Program background Green			
CH14	000-255	DMX to ArtNet mode			